


# B•KEYMO2

## AIRMOUSE-KEYBOARD REMOTE CONTROL



### TRANSMISSION AND CONTROL:

2.4G RF WIRELESS RADIO-FREQUENCY TECHNIQUE

KEY NUMBER: 81 KEYS

2.4G RF REMOTE CONTROL DISTANCE:  $\geq 10$  METER

2 AAA BATTERIES

TWO AAA\*2 BATTERIES

### LEARNING FROM OTHER DEVICES REMOTE CONTROL,

PLACE THE REMOTE HORIZONTALLY 4 INCHES FROM THE TOP OF THE BKEYMO2

TO PAIR FROM THE OTHER IR KEY FUNCTIONS,

PRESS AND HOLD ON ONE OF THE IR LEARNING KEYS TO ACTIVATE  
UNTIL THE LED INDICATOR FLASHES

FROM THE ORIGINAL DEVICES REMOTE CONTROL,

PRESS AND HOLD THE BUTTON YOU WANT LEARNED UNTIL THE LED LIGHT STOPS FLASHING  
REPEAT THE PROCEDURE

### KEYBOARD FUNCTIONS:

BACKSPACE

DELETE PREVIOUS CHARACTER

CAPS

CAPS LOCK

ENTER

PROCEED

SPACE

SPACEBAR

ALT

SWITCH TO NUMERIC CHARACTERS